



Powerware

LanSafe v. 5.1.3 Operating Systems Support*

Windows

Windows 2000 (Server, Advanced Server, Professional)

Windows XP Home
Windows XP Professional ¹

Windows 2003 Server (Web, Small Business)
Windows 2003 Server (Standard, Enterprise) ^{1,2}
Windows 2003 Server R2 (Standard, Enterprise) ¹

Windows Vista (Ultimate, Home Premium, Business)** ^{1,2}

Linux - UNIX - Macintosh

HP-UX

v. 10.20, 11.0, 11i (11.11) for PA-RISC ²
v. 11i v1.6 (11.22) for Itanium ²
v. 11 v. 2 (11.23) for Itanium ²

IBM AIX

v. 4.3.2 for RISC
v. 4.3.3 for RISC and PowerPC ^{3 1}
v. 5.1, 5.2, 5.3 for PowerPC ^{3 2}
v. 5.3 for PowerPC ^{5 2}

Mac OS v. 10.2.8, 10.3.x, 10.4.x

Red Hat 7.2, 8.0, 9.0
Red Hat Enterprise Linux 3 and 4 (ES and AS)
Red Hat Enterprise Linux 4 (ES, AS, and Desktop) ¹
Red Hat Enterprise Linux AS v. 2.1 and v. 3 ²
Fedora Core 5 ¹

SCO Unix OpenServer v. 5.0.6, 5.0.7

SGI Irix (MIPS) v. 6.5.2.x ¹

Sun Solaris

v. 7, 8, 9, 10 for SPARC
v. 7, 8, 9, 10 for Intel

SuSE Linux v. 7.2, 8.0, 8.2, 9.0, 9.3, 10.0
SuSE Enterprise Linux Server 8 and 9 ¹

Novell NetWare

Novell NetWare v. 5.0, 5.1, 6.0, 6.5 (must upgrade to latest SP)

* Check www.powerware.com for most recent software updates and versions

April 09, 2008

** Serial and Ethernet UPS connections only

¹ Supports 32 and 64 bit processors

² Supports 64 bit processors