



Package Contents

- SPA932 Attendant Console
- Attachment Arm
- Two (2) Attachment Arm Screws
- Auxiliary Cable
- Desktop Stand
- Quick Installation

32 Button Attendant Console for the SPA962 IP Phone

Quick Installation



1

Connecting to the SPA962

- A** Turn both the SPA962 and SPA932 face down.
- B** Align the hole in the SPA962 alignment recess with the hole on the attachment arm.
- C** Using the attachment arm screw, secure the attachment arm to the SPA962.



- C** Align the hole in the SPA932 alignment recess with the hole on the attachment arm.
- D** Using the attachment arm screw, secure the attachment arm to the SPA932.



IMPORTANT: Do not plug a telephone line cord into an AUX port. Use only the auxiliary cable provided with the SPA932.

- F** Locate the AUX IN port on the back of the SPA932. Connect one end of the auxiliary cable to this port.



- G** Locate the AUX port on the back of the SPA962. Connect the other end of the auxiliary cable to this port.



- H** Route the auxiliary cable inside the cable relief channel.
- I** Attach the appropriate desktop stand to each unit. The SPA932 is powered via the auxiliary cable with the SPA962. No additional power source is required.

2

Connecting a Second SPA932

A maximum of two (2) SPA932 Attendant Consoles can be connected to a SPA962. The instructions below are for connecting a second SPA932. If you are not attaching a second SPA932, skip to section 3.

- A Align the hole in the first SPA932 alignment recess with the hole on the attachment arm.
- B Using the attachment arm screw, secure the attachment arm to the first SPA932.



- C Align the hole in the second SPA932 alignment recess with the hole on the attachment arm.
- D Using the attachment arm screw, secure the attachment arm to the second SPA932.

3

Programmable Options

IMPORTANT: Do not plug a telephone line cord into an AUX port. Use only the auxiliary cable provided with the SPA932.

- E Locate the AUX OUT port on the back of the first SPA932. Connect one end of the auxiliary cable to this port.
- F Locate the AUX IN port on the back of the second SPA932. Connect the other end of the auxiliary cable to this port.



- G Route the auxiliary cable inside the cable relief channel.
- H Attach the appropriate desktop stands to each unit. The SPA932 is powered via the auxiliary cable with the SPA962. No additional power source is required.

To program the SPA932 Attendant Console, refer to the Attendant Console Configuration page in the SPA962 phone menu. For detailed information regarding these features, refer to the SPA900 Series Administration Guide.

For product compliance information refer to the SPA IP Phone User Guide, available on <http://www.linksys.com/>

LINKSYS[®]
A Division of Cisco Systems, Inc.

For additional information or troubleshooting help, contact your Service Provider.

Website
Inside the United States:
<http://www.linksys.com>
Outside the United States:
<http://www.linksys.com/international>

Linksys is a registered trademark or trademark of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. Copyright © 2007 Cisco Systems, Inc. All rights reserved.